

***X-Pro-USB-Interface
Step 2
USB-Driver-Installation***



Release: 02/06

Installation Guide, Step 2 for ***Hacker X-Pro-USB-Interface***
Connecting the USB_interface to the computer

- Now the enclosed USB interface can be connected with a free USB connection of your computer. The installation assistant for new hardware starts automatically. Mark "software automatically install" and continue with "next"



- If you find the following message, please click "install" to continue.




-the next picture shows the final:




-start the HACKER X-PRO Software with a Doubleclick on the HACKER-Icon



- the Hacker X-PRO Software starts and the green light show the correct connection to the USB-interface



- if the hacker X-PRO ESC is connected to the interface also the ECS surface lights green. The software shows the attitudes.



- make the desired attitudes now and send these over the Button "send settings" to the HACKER X-PRO ESC. The successful transmission can be recognized by the status surface "OK". X-PRO ESC is now finished programmed and can be used. Tipps to the attitudes can find you under "help".

If you have any questions, feel free to contact us.

Hacker Motor GmbH

**Hummler Str. 5
85416 Niederhummel
Deutschland**

Tel.: +49-8761-752 129

Fax.: +49-8761-754 314

Email: info@hacker-motor.com

Web: www.hacker-motor.com